

STNR | Residential Surface Mount / Retrofit Installation

Ideal for any application that allows the nosing to be mounted with adhesive. Install on existing stair nosings, step edges, or deck edges – Interior or Exterior. This product may be applied to any clean, dry, and flat surface including concrete, aluminum, wood, and composite decking.

Installation Steps:

1. Attach glow strip to nosing.
2. Use a construction-grade water-resistant, polyurethane, flexible adhesive.
3. Verify surface is dry, flat, and smooth.
 - On concrete, use a leveling compound if necessary, to provide a level/smooth surface.
4. Clean the surface that nosing will be applied to.
 - Use a dry cloth and non-residue cleaning compound (such as rubbing alcohol) to remove dirt, grime, moss, and mold.
5. Place nosing snug against front edge of tread and centered between sides.
6. Adhere to surface with Gorilla Heavy Duty Construction Adhesive (product #SP0090F, bonds aluminum).
 - Apply continuous bead of adhesive (centered) on underside of nosing.
 - Place and press nosing centered on front edge of tread.
 - Tape the nosing in place with painter's tape while curing.
 - Allow adhesive to cure for rated cure time before using stairs.

Installation Inspection:

Check regularly for loose nosings or damaged components. Replace damaged components, repair delaminated Photo-Glo components as required.

Photo-Glo Charge Instruction:

Minimum of 1-foot candle (11 Lux) of natural, fluorescent, incandescent or LED (light emitting diode) for 60 Minutes is required to charge Photo-Glo.

If you have further questions, please contact us:

Call: 1-855-723-6673 Email: sales@safetnose.com