

## STN | Maintenance

### Cleaning:

Establish a regular inspection schedule for the photoluminescent components and clean them as needed to prevent dirt, etc. from inhibiting the performance of the components. Safe-T-Nose, Inc. recommends inspection at least annually or after any particularly heavy use. Perform inspections in accordance with applicable local and national code requirements.

Photoluminescent components attached to floor assemblies may be cleaned by mopping, using high-pressure water (NO STEAM CLEANING) or wiping with a clean damp cloth. Use mild detergents to clean the photoluminescent components, if necessary. Mild dish washing detergents or laundry detergents are recommended. Do not use highly alkaline detergents, those having a pH >8, or acidic cleaners, those having a pH <5. Do not use abrasive cleaners. Photoluminescent components on walls or other assemblies or components may be cleaned using clean water and a clean sponge or a clean cotton cloth. Rinse after applying detergent solution. Wipe with a clean cotton cloth to dry.

### Regular Maintenance:

Inspect exit path markings, obstacle markings and photoluminescent stair nosings for damaged components and to ensure that photoluminescent components remain properly attached to their substrate and that no loosening of anchors or delamination of photoluminescent components has occurred.

Replace damaged components. Repair delaminated photoluminescent components. Contact the factory for repair recommendations. Delaminated photoluminescent components in stair nosings can result in trip hazard.

If you have further questions, please contact us:

Call: 1-855-723-6673    Email: [sales@safetnose.com](mailto:sales@safetnose.com)